R.O. WATER PURIFIERS · WATER DISPENSERS

Pure Water Top-Loading Bottled Water Dispenser

PURE WATER

No purification · Top-loading bottle · Hot and cold water · Compressor cooling

Compact water dispenser that runs on a top-loaded water bottle and delivers hot and cold water. It has no purification system and can be installed anywhere without a mains connection.

Stainless steel tanks, compressor cooling and an automatic thermostat keep the water at the ideal temperature; the hot water faucet has a child lock.

COLD WATER **8 – 12** °C · 2 L/h	HOT WATER **85 – 95** °C · 5 L/h
COLD TANK **2.5** L stainless	HOT TANK **1** L stainless



01 HOT AND COLD WATER

Reservoir	Tank	Temperature	Capacity
Cold water	2.5 L stainless steel	8 – 12 °C	2 L/h
Hot water	1 L stainless steel	85 – 95 °C	5 L/h

The hot water faucet has a child lock. The unit does not purify water; it is used with bottled water.

02 OPERATING CONDITIONS

Water source	Top-loading bottle (no purification)
Power supply	220 – 240 V AC, 50 Hz
Cooling	Compressor, R134A refrigerant
Cooling tubing	Copper

03 TECHNICAL SPECIFICATIONS

Stock code	3-08-PWD
Unit size	280 × 290 × 840 mm
Faucets	Hot (child lock), cold
Protection	Overcurrent and dry-run protection
Colour	White

ADDRESS
Beylikdüzü OSB, Bakır ve Pirinççiler Industrial Estate
Karanfil St. No: 3, 34520 Beylikdüzü, Istanbul, Türkiye

CONTACT
T +90 (212) 914 14 34
info@hscwater.com.tr

WEB
hscwater.com

04 FEATURES

- Dry-run protection
- Automatic temperature control (thermostat)
- Hygienic stainless steel tanks
- Quiet operation; suitable for homes and offices
- Powerful heating and cooling, low energy consumption

05 APPLICATIONS

- Offices and workspaces
- Homes
- Areas without a mains water connection
- Waiting rooms

06 INSTALLATION AND MAINTENANCE

01 Place the dispenser on a level floor at least 10 cm from the wall; after transport, leave it upright for 2 hours before switching on.

02 Remove the bottle cap and clean the neck; turn the bottle upside down and seat it in the top holder.

03 Open first the cold, then the hot faucet until water flows; do not switch on the heater before the hot water tank is full.

04 Plug in the unit and switch on the hot and cold switches; discard the first few glasses of water on first use.

> The hot water faucet has a child lock; take care when children use the dispenser. Clean the dispenser every 3 – 6 months; if it will not be used for a long period, unplug it and empty the tanks.

07 LOGISTICS

Model	Box Size (mm)	Box Weight
Bottled water dispenser	325 × 295 × 865	10 kg

Vehicle	Pallets	Boxes / Pallet	Palletised	Loose
20' Container	10	24	240 pcs	448 pcs
40' DC Container	20	24	480 pcs	896 pcs
40' HC Container	20	32	640 pcs	896 pcs
Curtain-side Truck	26	32	832 pcs	1,024 pcs

Pallet size: 100 × 120 cm (ISO pallet).



Product



Box

The technical values in this document are for information purposes only and were obtained under standard test conditions. Actual performance may vary depending on water quality, temperature, pressure and operating conditions. HSC Water reserves the right to change technical specifications without prior notice as part of ongoing product development.

ADDRESS
Beylikdüzü OSB, Bakır ve Pirinççiler Industrial Estate
Karanfil St. No: 3, 34520 Beylikdüzü, Istanbul, Türkiye

CONTACT
T +90 (212) 914 14 34
info@hscwater.com.tr

WEB
hscwater.com